

Thanks for trying our products! We know you'll love G2 quality and innovation.

Here is our full range of G2 products. To order or learn more, please log on at www.g2ergo.com.



Quick-Turn Throttle Tube
Opens faster than stock!



Billet Replacement Throttle Tube
2 piece design allows cam adjustability!



Competition Handguard System
Unique clamp design allows better cable routing!!



Nylon Bar End Mount Kit
Best handguard mounts...period!



Billet Grip Protector
Stop changing grips after every wipe-out!



Control Perch Spacer
Improved lever fit for big hands!

"The Coolio" (Installation instructions)

- 1) Locate an area of hose in your ATV cooling system for Coolio installation. Area must be at least 5 5/16" (135mm) in length for best fitment. Also, make sure there is proper clearance so Coolio does not touch engine cylinder, frame, wiring, etc. Mark both ends of this area.
- 2) From these marks, measure in (towards middle) 3/4" (18mm) and cut. Total length of hose removed should be no more than 3 7/8" (99mm).
- 3) Slide hoses clamps (included) over cut ends. Position hose clamp tightening screws in direction for best access to tighten.
- 4) Slide Coolio nipples into cut ends, then tighten hose clamps.



G2 ERGONOMICS CORP WILL NOT BE RESPONSIBLE FOR IMPROPER INSTALLATION OR USAGE OF THIS PRODUCT. Please follow all instructions provided. If you are unsure of any installation procedure, please contact your local motorcycle dealer.

For more information, please logon to www.g2ergo.com, or see your local dealer.